

OREGON®

POWERsharp®

DIAMOND

Precision Saw Chain Sharpening System

SHARPENS
ON THE SAW, ON THE JOB,
IN SECONDS™

Take the Next Leap in Saw Chain Technology

PowerSharp® is an easy-to-use, precision sharpening system that gives chain saw users the power to sharpen their chain in a matter of seconds with a simple-to-use attachment.

Fast. From dull to sharp in as little as 3 seconds.

Easy. Only three steps to faster, easier cutting.

Portable. Bar-mount sharpener is lightweight, durable, and highly visible.

Precise. Exact alignment between cutter and honing surface for perfect angles and knife-sharp edges.

Tough. PowerSharp® chain is as durable and hardworking as other OREGON® 3/8" pitch, low-profile chain.


Patent Pending

Patent-pending features make PowerSharp® a major advance over other sharpening methods - past or present

As the chain moves through the bar-mount sharpener, the unique top-sharpening cutters contact the stone.

The guidance drive link works together with the cutter, cutter depth gauge, and depth gauge tie strap to provide the stability required to create a precision cutting edge.

The diamond-coated dresser link resurfaces the stone, ensuring flat cutter to stone contact.



Easy to Use

PowerSharp® is a system that includes the PowerSharp® chain, the PowerSharp® guide bar, and the PowerSharp® bar-mount sharpener. Together, they work to make sharpening simple and easy.



ATTACH

When the chain dulls from normal use, dirt contact, or rock strikes, simply attach the bar-mounted sharpener to the PowerSharp® guide bar. Twin guide holes in the tip of the bar make perfect alignment fool proof.



SHARPEN

Press the tip of the sharpener to a solid surface for 3-5 seconds.



CUT


And it's back to the job, working faster with less effort.

Fast and Convenient

Arborists, farmers, and homeowners will all find the simplicity, portability, and speed of PowerSharp® indispensable. Whether the job is heavy limbing, storm clean-up, or trimming trees around the house, a sharp chain makes the work faster and easier.



HOMEOWNERS will have the confidence to keep their chain in top condition.



FARMERS AND RANCHERS will find sharp chain is as close as the nearest toolbox.



ARBORISTS AND LANDSCAPERS can stay in the cut and on the job.

Fits Most Popular Chain Saw Brands

	14" Stihl®	14" Craftsman®, Poulan®, Homelite® (and other models)	16" Stihl®	16" Craftsman®, Poulan®, Homelite® (and other models)	18" Craftsman®, Poulan®, Homelite® (and other models)
Chain & Sharpening Stone	PS50	PS52	PS55	PS56	PS62
Bar-Mount Sharpener w/Bar	539454	539453	539456	539455	539457
Starter Kit (includes all of the above components)	541219	541220	541221	541222	541223



WARNING! All saw chain can kick back, which may result in severe injury to saw operator or bystander. Operate your saw safely. Read and follow all warnings in your saw operator's manual and OREGON® chain safety and maintenance instructions.



OREGON® provides original equipment to the industry and has been the world leader in saw chain since 1947.

OREGON® | Blount, Inc. PO Box 22127 Portland, OR, U.S.A. 97269-2127 Phone: 503-653-8881 Fax: 503-653-4201 Web: oregonchain.com
 OREGON Distribution LTD. 505 Edinburgh Rd. N., Guelph, Ontario, Canada N1H6L4 Phone: 519-822-6870 Fax: 519-822-4999