

GSi 30 chainsaw

The GSi 30 battery-powered chainsaw is the ideal tool for cutting branches of small to medium diameter, or for small woodworking tasks.

The tool-free chain adjustment and compact, ergonomic design ensure easy operation and comfort for the user.

Brushless motor: reduces power absorption and ensures long-term durability.

Tool-free chain adjustment. The guide bar and chain can be adjusted without using tools, thanks to a large knob that provides an agile and comfortable grip. **(1)**

12" guide bar and chain. The 12" guide bar enables the chainsaw to smoothly cut through wood up to medium thickness.

Oil tank with externally visible level: clearly indicates when top-ups are needed. **(2)**

Soft handgrip. Helps to ensure a secure and comfortable grip on the machine during cutting operations. **(3)**

Ergonomic design: the battery can be easily inserted and removed without any effort.



GSi 30 chainsaw - technical specifications



MOTOR		
TYPE		brushless
MAX POWER	W	900W
VOLTAGE	V	40
BATTERY	Ah	5
RUNNING TIME	cut	160
MAX RPM AT NO LOAD	rpm	8500 ±10
SAFETY		
NOISE PRESSURE (LpA av EN 11681-1, EN 22868)	dB(A)	86,7
NOISE POWER (LWA 2000/14/EC, EN 22868, EN ISO 3744)	dB(A)	99
VIBRATION LEVEL (EN 11681-1, EN 22867, EN 12096)	m/s ²	4,3 (SX) – 5,4 (DX)
UNCERTAINTY (EN 12096)	m/s ²	1,0
ERGONOMICS		
FRONT HANDLE		Plastic
REAR HANDLE		Plastic with soft grip
CUTTING SYSTEM		
BAR LENGHT	cm (inch)	30 (12")
CHAIN PITCH / GAUGE	inch	3/8" x .043"
CHAIN BRAKE		Inertial
CHAIN SPEED	m/s	16
OIL TANK VOLUME	l	0,2
OIL PUMP		automatic/zero oil flow with motor stopped
CHAIN TENSIONER		tool-free, knob system
HOOK		Plastic
HOMOLOGATIONS		
WEIGHT (without battery, bar and chain) (with 5.0 Ah battery)	kg	2,8 (4,1)